


Blanketrol III

Turn unit on, press “temp set” button, before performing the following


- Resetting “PM Required” message and removing error code in right display and hours until PM

Simultaneously press the following:



- Resetting error message in central display

Simultaneously press the following:



- **Monitor the total operating hours in manual mode**
Press simultaneous following buttons



- **Monitor hours to PM in manual mode**
Press simultaneous following buttons

